


# **H** TECHNICAL PROCEDURE

## TRAILER SUSPENSION SYSTEMS CXST SELF-STEER SUSPENSION

**SUBJECT:** CONNEX® ST Maintenance Procedures

**LIT NO:** T62001  
**DATE:** July 2022

**REVISION:** C





**TABLE OF CONTENTS**

**Important Safety Notices ..... 3**

**Conventions Applied in This Document..... 3**

    Explanation of Signal Words ..... 3

    Hyperlinks ..... 3

    Contacting Hendrickson..... 3

    Relative Literature ..... 4

**Self-steer Axle Components and Lubrication Points ..... 5**

**Introduction ..... 6**

    About self-steering ..... 6

    Tools And Equipment..... 6

    Preventative Maintenance ..... 6

        General Inspection..... 6

    Suspension Lubrication ..... 6

**Lock-Straight System ..... 7**

    Lock-straight Air Controls ..... 7

    Lock-straight Assembly Inspection ..... 8

    Lock-straight Center Adjustment..... 8

    Replace Lock-Straight Arm assemblies ..... 8

**Tie Rod Maintenance..... 9**

    Remove Tie Rod Bracket ..... 9

    Replace Tie Rod or Tie Rod End..... 10

    Reattach Tie Rod ..... 10

    Reinstall Tie Rod Bracket..... 11

**Axle Maintenance ..... 12**

    Axle component Inspection..... 12

        Kingpin Bushing Inspection ..... 12

        Kingpin Bushing Replacement ..... 13

        Remove wheel-end components..... 13

        Disconnect Tie Rod From Steering Knuckle..... 13

        Kingpin Disassembly ..... 13

        Kingpin Reassembly..... 15

        Installing Kingpin Caps..... 17

    Wheel-cut Adjustment ..... 18

**Brake Components..... 18**

**Appendix A: Terms and Definitions ..... 19**

**Appendix B: Fastener Torque Specifications ..... 20**



### IMPORTANT SAFETY NOTICES

Hendrickson literature number T12007 Technical Procedure General Safety Precautions and Information, available at [www.Hendrickson-intl.com/TrailerLit](http://www.Hendrickson-intl.com/TrailerLit), includes important preparation, precautionary and safety information pertaining to the procedures included in this document.

To help prevent personal injury and equipment damage; warnings, cautions and other relative statements included in Hendrickson literature number T12007 are to be read carefully and applied during the performance of the procedures included in this document.

Improper maintenance, service or repair can cause damage to the vehicle and other property, personal injury, unsafe operating conditions and potentially void the manufacturer’s warranty.

### CONVENTIONS APPLIED IN THIS DOCUMENT

Various techniques are used in this document to convey important information, express safety issues, provide methods for CONTACTING HENDRICKSON and how to identify and apply HYPERLINKS.

### EXPLANATION OF SIGNAL WORDS

Hazard signal words (such as DANGER, WARNING or CAUTION) appear in various locations throughout this publication. Information accented by one of these signal words must be observed at all times. Additional notes are utilized to emphasize areas of procedural importance and provide suggestions for ease of repair. The following definitions comply with ANSI Z535.6 and indicate the use of safety signal words as they appear throughout the publication.

**▲DANGER** Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

**▲WARNING** Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

**▲CAUTION** Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**NOTICE** Indicates information considered important, but not hazard-related (e.g. messages relating to property damage).

**IMPORTANT:** An operating procedure, practice or condition that is essential to emphasize.

**▲ or ▲** **Safety Alert Symbol** used to indicate a condition exists that, if not avoided, may result in personal injury or harm to individuals. It must be applied to DANGER, WARNING and CAUTION statements, which emphasize severity.

### HYPERLINKS

Hyperlinks are identified by a dark grey line under the linked text. Internal links allow the reader to jump to a heading, step or page in this document. External links open the website or document referenced. While viewing electronically, activate the hyperlink by clicking on the underlined text.

### CONTACTING HENDRICKSON

Contact Hendrickson Trailer Technical Services for technical assistance as needed. To do so, several options are available. Technical Services must be contacted before performing any warranty related service.

**NOTE: DO NOT** service a suspension or any component that is under warranty without first contacting Hendrickson Technical Services.

Prior to contacting Technical Services, it is best to have the following information about the vehicle and Hendrickson suspension available (all that apply):

- **Hendrickson suspension** information, (refer to L977 Suspension and Axle Identification) –
  - Suspension model number
  - Suspension serial number
  - Approximate number of suspension miles
- **Trailer information** (located on VIN plate) -
  - Type (van, reefer, flat bed, etc...)
  - Manufacturer
  - VIN (vehicle identification number)
  - In-service date<sup>1</sup>
  - Fleet/owner name
  - Unit #

<sup>1</sup> If the in-service date is unknown or not available, the vehicle date of manufacture will be substituted.



- **Failure information**
  - Description of the system problem, the part number and/or the part description of the reported non-functioning part.
  - **Date of failure.**
  - Where applicable, **location of problem** on suspension / trailer (e.g., road side, front axle, rear axle, curb side rear, etc.).
- **Digital photos** of suspension and damaged areas.
- **Special application** approval documentation (if applicable).

**PHONE**

Contact **Hendrickson Trailer Technical Services** directly in the United States and Canada+ at **866-RIDEAIR (743-3247)**. From the menu, select:

- **Technical Services/Warranty** for technical information.
- Other selections include:
  - **Aftermarket Sales** for replacement parts information and ordering.
  - **Original Equipment Sales** for parts inquiries and ordering for trailer manufacturers.

**EMAIL**

[HTTS@Hendrickson-intl.com](mailto:HTTS@Hendrickson-intl.com)

Contact Hendrickson for additional details regarding specifications, applications, capacities, and operation, service and maintenance instructions.

All applications must comply with applicable Hendrickson specifications and must be approved by the respective vehicle manufacturer with the vehicle in its original, as-built configuration.

**RELATIVE LITERATURE**

If you suspect your version of this or any other Hendrickson manual is not “up-to-date”, the most current version is free online at:

[www.Hendrickson-intl.com/TrailerLit](http://www.Hendrickson-intl.com/TrailerLit)

Available Hendrickson documentation can be viewed or downloaded from this site.

All Hendrickson online documentation is in PDF format that requires PDF reader software to open. A free application is downloadable from Adobe at <http://get.adobe.com/reader/>.

Other relative literature may include:

NAME	DESCRIPTION
Various	Installation drawing, contact Hendrickson
B106	Pivot Bushing Inspection Procedure
L459	Checking Trailer Ride Height
L578	Inspection and Lubrication
L579	Alignment Procedures
L583	Comprehensive Warranty Statement
L974	Drum Brake Maintenance Procedures
T12007	General Safety Precautions for Technical Literature
L1250	Trailer Self-Steer Suspension Application Guide
L1277	CONNEX® ST Parts List
T61001	Self-steer Suspension Installation and Requirements

Table 1: Relative Literature

Hendrickson reserves the right to make changes and improvements to its products and publications at any time. For the latest version of this manual Consult the Hendrickson website:

[www.Hendrickson-intl.com/TrailerLit](http://www.Hendrickson-intl.com/TrailerLit)


**PREPARING TRAILER FOR MAINTENANCE SERVICE**

Information for trailer preparation, safety and precautionary statements, refer to Hendrickson literature number T12007, available at [www.Hendrickson-intl.com/TrailerLit](http://www.Hendrickson-intl.com/TrailerLit).

**NOTE: DO NOT** service a suspension or any components that is under warranty without first contacting Hendrickson Technical Services. Refer to CONTACTING HENDRICKSON for details.

**⚠WARNING DO NOT** work under a trailer supported only by jacks. Jacks can slip or fall over, resulting in serious personal injury. Always use safety stands to support a raised trailer.

## SELF-STEER AXLE COMPONENTS AND LUBRICATION POINTS

**Lock-straight Assembly (bottom view)**

*Figure 1: Self-steer axle components*

LOCK-STRAIGHT ASSEMBLY COMPONENTS	
Item	Description
1	Lock-straight air actuator
2	Actuator plate (x2)
3	Lock-straight air chamber
4	Arm assembly (x2)
5	Locking assembly (welded to axle)
6	Tie rod bracket
7	Stop bolt and jam nut (x2)
8	Locking clamp (x4)
9	Tie rod washer (x2)

AXLE COMPONENTS	
Item	Description
10	Kingpin assembly(x2)
11	Draw key
12	Steering knuckle (x2)
13	Wheel-cut stop bolt and jam nut (x2)
14	Tie rod ends (x2)
15	Locking clamp (x2)
16	Steering arm assembly (x2)
17	Cam tube (x2)
18	Brake spider (x2)

*Table 2: Self-steer axle component descriptions*

POINT	GREASE FITTING	ACTION	FREQUENCY
A	Kingpin, top & bottom	Lubricate with NLGI #2 EP grease	Quarterly
B	Cam tube		Monthly
C	Tie rod end		
D	Arm assembly pivot		

*Table 3: Lubrication points*

## INTRODUCTION

### ABOUT SELF-STEERING

The suspension is designed to self-steer while the trailer is moving forward only. If the wheels are not locked straight or lifted while moving in the reverse direction, the wheels may steer left or right to the wheel-cut position. This could result in scrubbing of the tires or damage to suspension components. For more information, refer to LOCK-STRAIGHT SYSTEM on page 7.

### TOOLS AND EQUIPMENT

The following tools and equipment are necessary to complete the procedure within this publication:

- Refer to APPENDIX B: FASTENER TORQUE SPECIFICATIONS on page 21 for wrench/socket sizes.
- 3/8 inch pin punch or equivalent.
- 12 foot (minimum) steel tape measure with 1/32 inch increments.
- Dial indicator with magnetic base.
- Kingpin removal tool.
- Tire changing equipment (as needed).
- Angle measuring instrument (magnetic protractor) for self-steer axle.
- Wheel chocks.
- Frame jacks or supports.

### PREVENTATIVE MAINTENANCE

To ensure the suspension system continues to operate and function safely, preventative maintenance practices must be performed. For recommended general suspension preventive maintenance procedures, refer to Hendrickson literature number L578. This section includes recommended preventative maintenance procedures relative to self-steer axle operation.

### GENERAL INSPECTION

In preparation for all inspection procedures, refer to PREPARING TRAILER FOR MAINTENANCE SERVICE on page 4. It may not necessary to lift the trailer.

Table 2 and Table 3 on page 5 list inspection and lubrication points respectively for self-steer axle components. A general inspection should include:

- A. Signs of wear, corrosion or damage.
- B. Loose or missing fasteners and components.
- C. Weld integrity of all welds.
- D. Integrity of air systems; no leaks in hoses or fittings.
- E. Operationally check performance to ensure all moving parts functioning normally.

## SUSPENSION LUBRICATION

In most instances, among others, lubrication serves two primary purposes:

- A. Minimize the effects of friction (wear and heat) between two or more surfaces in close proximity to each other and share relative motion.
- B. Remove air from voids which, if not otherwise filled, may harbor harmful contaminants (moisture, debris, etc.).

Figure 1 on page 5 includes required lubrication points for the self-steer axle. The required grease is NLGI #2 EP. Prior to replenishing grease, clean area around each grease fitting and the associated joint.

### QUARTERLY REQUIREMENTS

- A. Kingpin - upper and lower grease fittings on the top and bottom of the steering knuckle. Apply grease until fresh grease can be seen exiting from joints shown in Figure 2.




Figure 2: Kingpin Lubrication

### MONTHLY REQUIREMENTS:

- A. Cam tube - one grease fitting for each. Apply grease until fresh lubricant can be seen at the slack adjuster end.
- B. Tie rod end - one grease fitting for each. Apply grease until the rubber boot expands.

### NOTICE

Over greasing can rupture the rubber boot, allowing grease to escape and contaminants or debris to enter.

- C. Slack adjuster (not shown) - apply grease according to vendor recommendations.



- D. Locking arm - one grease fitting for each arm Figure 3.




Figure 3: Locking arm lubrication

### LOCK-STRAIGHT SYSTEM

The lock-straight system is used to:

- A. Dampen self-steering of the wheels while the trailer moves forward.
- B. Hold the wheels straight forward and the tie rod in center position while the trailer moves in reverse.

### FORWARD MOVEMENT

When moving in the forward direction, wheels will self-steer with the vehicle. If not restrained, the wheels will move erratically. The lock-straight system dampens steering by resisting tie rod movement.




Figure 4: Dampening action, steering to the right

While the trailer is operating, regulated 25±5 psi air pressure is continuously supplied to the actuator (Figure 4). Dampening is accomplished as the actuator attempts to expand at the front end of the lock-straight arms to hold the tie rod bracket and tie rod at the center position at the opposite end.

While moving forward, the air chamber (Figure 4) must remain disengaged (no air in the chamber) with its centering pin retracted.

### REVERSE MOVEMENT

**NOTICE** If the wheels are allowed to move to a wheel-cut position, they could lockup and scrape on the surface. This action can damage suspension components.

While traveling in reverse, if not properly managed, the wheels will quickly move to a wheel-cut position. This could result in scrubbing of the tires and possible suspension damage.

To prevent this, the air chamber (Figure 4) must be engaged (air in the chamber) to move its centering pin through the centering lock holes in the lock-straight assembly. See Figure 5 on page 8. Optionally, a lift control can be added to also lift the axle.

**IMPORTANT:** With air applied to the lock-straight chamber, the locking pin is engaged, but may not be aligned and through the centering holes of the assembly. Moving the trailer straight forward before moving in reverse will allow the actuator to align the wheels straight forward, center the tie rod bracket and align the locking pin with the centering holes.

### LOCK-STRAIGHT AIR CONTROLS

The CONNEX® ST suspension LOCK-STRAIGHT SYSTEM requires an air control kit for the air actuator and air chamber. Hendrickson recommends including an optional lift control kit with an applicable backup control.

While raised, the axle should be forced and held to the center position by the air actuator. Further, the wheels must be properly aligned when the axle is lowered for forward trailer motion. This will minimize scrubbing of the tires as wheels lower and contact the road surface.

As instructed in installation drawing D-36237<sup>1</sup>, the trailer OEM must supply all required air controls. Refer to manufacturer's documentation for information on OEM provided self-steer axle centering, lift and backup control kits.

<sup>1</sup> An installation drawing is provided with each CONNEX ST suspension. Generic versions are listed in Hendrickson literature number T61001 and available online at [www.hendrickson-intl.com/TrailerLit](http://www.hendrickson-intl.com/TrailerLit). Where duplication exists, refer to installation drawing.



**LOCK-STRAIGHT ASSEMBLY INSPECTION**

This inspection is recommended to ensure the lock-straight assembly is free of any obstruction or damage which could restrict movement.

Components to inspect include:

ITEM <sup>1</sup>	DETAILS
1	Lock-straight actuator Visually inspect for signs of wear in flex member.
3	Lock-straight air chamber - Ensure locking pin extends into holes when air is applied.
4	Lock-straight arm assembly - Ensure the arms move freely and unobstructed as the wheels are turned. The arms include bushings at the pivot connections. If showing signs of excessive vertical motion and/or wear, the arms should be replaced.
7	Lock-straight bolt and jam nut - Ensure locked in position by jam nut and contact with the arms when in center position.
8	Locking clamp - check to ensure clamp is tight <sup>2</sup> .
9	Tie rod washer - check to ensure in place and weld integrity is good.
N/A	Lock-straight contact points (Figure 5)- These four points must be contacting, metal-to-metal, when the lock-straight system is activated. Refer to <u>LOCK-STRAIGHT CENTER ADJUSTMENT</u> .

<sup>1</sup> Item numbers are from Figure 1 on page 5.  
<sup>2</sup> For torque values, refer to FASTENER TORQUE SPECIFICATIONS on page 21.

Table 4: Lock-straight inspection point details

**LOCK-STRAIGHT CENTER ADJUSTMENT**




Figure 5: Self-steer axle lock-straight assembly (Bottom view)

During axle alignment or other applicable adjustment of the self-steer axle, the tie rod and wheels (Figure 5) must be locked in the center position. Refer to *L579 Alignment Procedures* for needed adjustments.

Inspect arm assemblies for signs of wear, damage or loose fit. Replace if needed before continuing. See **REPLACE LOCK-STRAIGHT ARM ASSEMBLIES**.

**REPLACE LOCK-STRAIGHT ARM ASSEMBLIES**

The lock-straight system includes two opposing arms (Figure 5) with bushings located at the pivot bolts. Wear can occur at the four contact and pivot points. If worn or damaged, both arm assemblies should be replaced.

1. Follow LOCK-STRAIGHT CENTER ADJUSTMENT.
2. Relieve pressure at the trailer air tank to depressurize air in the lock-straight air actuator.
3. Remove the air hose feeding air actuator.




Figure 6: Removing lock-straight air actuator

4. Remove the air actuator (Figure 6) by extracting the air fitting and four mounting screws. **Set aside** for later reassembly.






Figure 7: Lock-straight arm assembly pivot bolt removal

5. Remove lock-straight arm pivot bolts (Figure 7) for both lock-straight arm assemblies.




Figure 8: Lock-straight arm assembly removal

6. Remove both lock-straight arm assemblies (Figure 8).
7. Reverse the above steps to install new lock-straight arm assemblies.
8. Tighten all fasteners to values specified in FASTENER TORQUE SPECIFICATIONS on page 21.
9. Follow LOCK-STRAIGHT CENTER ADJUSTMENT on page 8 procedure, refer to L579 Alignment Procedures, to adjust lock-straight center position.

## TIE ROD MAINTENANCE

### NOTICE

Steps must be taken to ensure lock-straight adjustments are returned to previous settings with wheels aligning straight when in centered position. Not doing so can result in improper toe, excess tire wear and/or erratic self-steer axle performance.

### REMOVE TIE ROD BRACKET

This bracket must be removed to replace the tie rod or tie rod end(s).

**IMPORTANT:** The tie rod bracket is aligned between the tie rod washers. If the tie rod washers have shifted for any reason or installing a new tie rod assembly, they will have to be realigned after reattaching the tie rod. Refer to L579 ALIGNMENT PROCEDURES.




Figure 9: Lock-straight tie rod bracket

1. Remove the four tie rod bracket locking clamp bolt, nut and washers (Figure 9). Save for reassembly.
2. Remove tie rod bracket.



## REPLACE TIE ROD OR TIE ROD END

Follow this procedure to replace one or both tie rod ends. Follow applicable steps for replacing the tie rod assembly.

**NOTE:** Tie rod ends have opposing left/right threads and must attach to the correct end of the tie rod.




Figure 10: Remove tie rod fasteners

1. **Remove** the cotter pin and castle nut on the tie rod end to be replaced (Figure 10). Remove from both ends if both tie rod ends or the entire tie rod assembly is to be replaced.

**NOTE:** New fasteners will be provided with the new tie rod or tie rod end.

2. If replacing the tie rod assembly (Figure 12), go to **REATTACH TIE ROD**.

### NOTICE

The clamp and bolt must be orientated as shown to avoid interference among moving parts.




Figure 11: Tie rod end disassembly

3. **Loosen** tie rod end locking clamp (Figure 11). It should not be necessary to remove tie rod end clamp hardware.
4. **Count and record** the number of turns required to **unthread** tie rod end from the tie rod and **discard**.

5. **While threading** the new tie rod end into the tie rod, **count** the number of turns and match the number of turns recorded in Step 4.
6. If removed, **replace** tie rod end clamp hardware, but **DO NOT** tighten.

**IMPORTANT:** The tie rod end clamp will be tightened after the tie rod is reassembled to the suspension. Be sure to add grease to tie rod ends when complete.

## REATTACH TIE ROD




Figure 12: Remove/attach tie rod assembly

1. **Clean** the area around the steering arm and the hole for the tie rod end(s).
2. **Insert** the tie rod end into the steering arm (Figure 12). If applicable, **repeat** for the opposite end.

**IMPORTANT:** If replacing tie rod assembly, visually check to ensure both tie rod ends extend the same length beyond the tie rod.

3. **Install** washer and tie rod end castle nut onto tie rod end(s) (Figure 10).
4. **Tighten** the tie rod end castle nut to the specified torque<sup>1</sup>, then advance to the nearest cotter key hole.

**IMPORTANT:** **DO NOT** back-off nut to align to cotter key hole.

<sup>1</sup> A complete list of torque values can be found at [FASTENER TORQUE SPECIFICATIONS](#) on page 20.




Figure 13: Tie rod end cotter key install

5. Insert the cotter pin through castle nut and tie rod end, as shown in Figure 13.

### REINSTALL TIE ROD BRACKET

During installation, the tie rod bracket must be properly centered and vertically aligned to prevent binding.

1. Install tie rod bracket, as shown in Figure 14, using hardware removed in Step 2 of REMOVE TIE ROD BRACKET on page 9. **DO NOT** tighten at this time.

**NOTE:** A new tie rod will include tie rod bracket clamps and tie rod washers, but may not include fasteners. These clamps will be tightened after realignment of the tie rod bracket.




Figure 14: Positioning tie rod bracket

2. Ensure the tie rod bracket is correctly positioned in the lock-straight assembly shown in Figure 14.
3. Manually lock the lock-straight assembly with a  $\frac{3}{8}$  inch pin punch (or equivalent) as shown in Figure 14.

**NOTE:** Alternately, air can be supplied to the lock-straight actuator, first, and, second, to the chamber to hold the tie rod bracket in position.

4. Temporary shim above and below tie rod bracket (Figure 14) to evenly space (center) the tie rod bracket vertically in lock-straight assembly.

5. Refer to *L579 Alignment Procedures* for alignment.
6. If tie rod washers (Figure 14) are loose, refer to installation drawing D-36237<sup>1</sup> for instructions on tack welding the washers in place.
7. Remove shims installed in Step 4.
8. Undo the temporary lock performed in Step 3.
9. Restore trailer to normal operating state.

<sup>1</sup> An installation drawing is provided with each CONNEX® ST suspension. Generic versions are listed in Hendrickson literature number T61001 and available online at [www.hendrickson-intl.com/TrailerLit](http://www.hendrickson-intl.com/TrailerLit). Where duplication exists, refer to installation drawing.



## AXLE MAINTENANCE

This section includes maintenance procedures specific to the CONNEX® ST self-steer axle and knuckle assembly. For maintenance applicable to the attached CXST suspension system and wheel-end, refer to Hendrickson literature number L578 and other related literature listed in T61001. For more information refer to CONTACTING HENDRICKSON on page 3.

## AXLE COMPONENT INSPECTION

Along with recommended preventive maintenance listed in Hendrickson literature number L578, refer to Table 5 for information and procedures relative to the inspection and maintenance of the CONNEX ST self-steer axle and lock-straight components.

ITEM <sup>1</sup>	DETAILS
<b>10</b>	Kingpin - Refer to KINGPIN BUSHING INSPECTION.
<b>11</b>	Draw key - ensure key is present and jam nut remains tight <sup>2</sup> .
<b>13</b>	Wheel-cut stop bolt and jam nut - ensure bolt is not missing and jam nut is tight <sup>2</sup> . Refer to WHEEL-CUT ADJUSTMENT on page 18.
<b>14</b>	Tie rod ends - steering is free and unobstructed through to stops, no leaks or damage to grease boot.
<b>15</b>	Locking clamps - Ensure tight <sup>2</sup> and positioned horizontal, facing rearward as shown in Figure 1 on page 5.
<b>17</b>	Cam tube - Refer to L974 Drum Brake Maintenance Procedures for S-cam, cam tube and other brake component inspection.
<sup>1</sup> Item numbers are from Figure 1 on page 5. <sup>2</sup> For torque values, refer to FASTENER TORQUE SPECIFICATIONS on page 21.	

Table 5: Axle inspection point details

## KINGPIN BUSHING INSPECTION

This inspection should be performed **quarterly** to check for possible excess wear and proper operation of the kingpin connection at both ends of the axle.

### Checking Upper Kingpin Bushing



Figure 15: Checking upper kingpin bushing

1. **Affix** a magnetic base dial indicator on the axle and place the tip of the dial indicator on the inside of the upper kingpin connection as shown in Figure 15.
2. **Set** the dial indicator to "0" zero.
3. **Move** the top of the tire in and out by applying reasonable, constant pressure and then releasing.
4. **Check and record** reading at both in and out positions on the dial indicator.

If the dial indicator moves more than 0.025", the upper bushing is worn or damaged. Replace both kingpin bushings. Refer to KINGPIN BUSHING REPLACEMENT on page 13.

**NOTE:** Kingpin service kits include bushings/seals only or bushings, seals and a kingpin for one side.

### Checking Lower Kingpin Bushing

5. **Affix** a dial indicator so the magnetic base is on the axle and the indicator tip is against the inside of the bottom of the knuckle, similar to Figure 15 for the upper kingpin bushing.
6. **Set** the dial indicator to "0" zero.
7. **Repeat** steps 3 and 4.

**IMPORTANT:** If either bushing is worn or damaged, it is mandatory to replace both the top and bottom bushings on that knuckle assembly and, if necessary, the kingpin.



## KINGPIN BUSHING REPLACEMENT

Applicable components must be replaced if damaged or worn beyond specifications as determined by KINGPIN BUSHING INSPECTION on page 12.

Use the following procedures to remove and replace the seals and bushings in both kingpin housings and replace the kingpin:

### REMOVE WHEEL-END COMPONENTS

This is recommended to ensure the performance of these procedures are safer and more manageable. These components can also interfere with disassembly and reassembly of parts.

1. Remove the wheel and drum.

**NOTE:** For wheel-end maintenance procedures, refer to applicable online RTR wheel-end maintenance procedures listed at [www.Hendrickson-intl.com/TrailerLit](http://www.Hendrickson-intl.com/TrailerLit).

2. Refer to the applicable wheel-end maintenance literature for procedures on how to remove the hub.
3. Remove the brake components from the spider. Refer to *L974 Drum Brake Maintenance Procedures* for details.

### DISCONNECT TIE ROD FROM STEERING KNUCKLE




Figure 16: Aligning tie rod lock plate

1. The tie rod bracket should be held in position by the lock-straight air chamber pin. If the centering pin is not in place, insert a 3/8 inch pin punch (or equivalent) as shown in Figure 14 on page 11.
2. Using wrench or socket<sup>1</sup>, remove the four locking clamp bolts (Figure 16) holding the tie rod bracket to the tie rod. Save for reassembly.

<sup>1</sup> Refer to FASTENER TORQUE SPECIFICATIONS on page 20 for tool sizes.

3. Remove the cotter pin (Figure 16) from the tie rod end castle nut.
4. Using wrench or socket<sup>1</sup>, remove the castle nut and washer from the tie rod end. Save for reassembly.
5. Using drift pin and hammer, push out the tie rod end from the steering arm and move the tie rod to a safe position.

### NOTICE

If the tie rod end is damaged, refer to REPLACE TIE ROD OR TIE ROD END on page 10.

### KINGPIN DISASSEMBLY




Figure 17: Kingpin exploded view

1. Remove top and bottom retaining rings (Figure 17) securing the kingpin caps in position.

**NOTE:** The service kit will include two retaining rings and kingpin cap assemblies.

2. Using wrench or socket<sup>1</sup>, remove grease fitting from each kingpin cap.

**NOTE:** This procedure uses a hex head screw to force the kingpin cap out of the kingpin housing assembly. Other methods may be applied, but must be safe and not damage the kingpin or kingpin housings.

3. Thread a 3/8-24 1 1/2 inch long (minimum length) hex head screw into the center hole, 1/8-NPT, of each cap.

- Turn screw into the center of the cap until the cap separates enough to **remove** it from the kingpin housing with a pry bar. **Discard** the cap and screw.

**NOTE: DO NOT** reuse the screw and cap. They will likely be damaged during cap removal.

- Repeat Step 4 to remove the opposite kingpin cap.




Figure 18: Wheel-cut bolt length measurement

- Measure** (Figure 18) and **record** current wheel-cut bolt length. Refer to [Table 6](#) on page 18.

**NOTE:** This value is required to restore bolt to its original length during reassembly. The length should be the same on both sides. The bolt interferes with draw key removal and must be removed.

- Remove** the wheel-cut bolt and jam nut. **Save** for reassembly in [Step 4](#) on page 17.

**NOTE:** The wheel-cut bolt is in the path of the draw key and must be removed.

- Using wrench or socket <sup>1</sup>, **remove** the draw key nut (Figure 18).
- Using drift pin and hammer, **remove** the draw key that engages the kingpin. **Discard** draw key.

**NOTE:** If removal of the draw key proves difficult, an air hammer can be used with a drift punch attachment.

**CAUTION** To avoid component damage and/or personal injury, the knuckle must be supported before removal of kingpin. Removal of kingpin will allow the entire steering knuckle to separate from the suspension.

- Remove** the kingpin by pushing it through the knuckle assembly and axle end in either direction. **Discard** kingpin.

**NOTICE** DO NOT heat the axle to remove the kingpin. If necessary, refer to [CONTACTING HENDRICKSON on page 3](#) for assistance.




Figure 19: Steer knuckle removal

- Remove** the steer knuckle (Figure 19) by sliding it off the axle end. The thrust washer will fall from the connection.

- Discard** thrust washer.

**NOTE: DO NOT** reuse the thrust washer. A replacement is included with the service kit.

**NOTE:** A Hydraulic press with a minimum force capacity of 5 tons will be required for this procedure.

**WARNING** Before applying Hydraulic pressure to any tooling set-up, always check to ensure the press plate, adapters and components being worked on are positioned properly, I.E. "IN LINE" with the ram of the press. Improper positioning can cause personal injury and/or component damage.

- Thoroughly** clean all machined surfaces.

- Place knuckle in a hydraulic press.

- Make sure to support in between the knuckle plates when pressing out the kingpin housing and ensure that the kingpin housing sits in line with the press.

16. **Press** out each kingpin housing assembly by forcing it inward to the knuckle (Figure 20).




Figure 20: Removing kingpin bushings

17. Inspect exposed machine surfaces of the knuckle to ensure surfaces are clean and corrosion free.
18. Make sure the knuckle bore diameter measures  $2.996 \pm .001$ .
19. Correctly position new kingpin housing assemblies, upper and lower, and press them in place one at a time until fully seated.
- A. To determine if the steer kingpin housings are fully seated verify that the steer kingpin housing to kingpin housing distance is  $5.455 \pm .015$  (Figure 21).




Figure 21: Kingpin housing distance

20. Check alignment by sliding the new kingpin through both kingpin housings to ensure no binding is present (Figure 24 on page 16).
- A. Inspect kingpin housings for burrs or other obstructions.
- B. Check for damage or deformation in knuckles.

### KINGPIN REASSEMBLY

Following this procedure for recommended kingpin assembly.

1. **Thoroughly clean** the contact surfaces for the steering arm and tie rod end (Figure 19 on page 14). **Thoroughly clean** the hole in the axle end for the kingpin (Figure 23).
2. **Slide** kingpin into axle end to ensure it moves easily in and out. If not, return to Step 2.
3. **Remove** kingpin.




Figure 22: Steer knuckle installation

4. **Position** the steer knuckle (Figure 24 on page 16) over the axle end and align to kingpin hole.




Figure 23: Kingpin

**IMPORTANT:** If not clearly marked, the top of the kingpin can be determined by measuring the distance from the draw key notch to each end. The top is the end with the longest dimension.



**NOTICE**

If the kingpin is not closely aligned relative to the draw key, the draw key and/or kingpin can be damaged during draw key insertion.




Figure 24: Kingpin orientation

5. Orient kingpin above the steer knuckle (Figure 24) so the draw key notch is facing the draw key passage.
6. Slide kingpin into the housing assembly and at least half way into the axle end.

**NOTICE**

If necessary, use a rubber hammer to knock kingpin into position.




Figure 25: Thrust Washer




Figure 26: Installing thrust washer

7. Insert thrust washer, dimples facing down (Figure 26), between lower kingpin housing assembly and axle end (Figure 26).

8. Continue to insert the kingpin until the draw key notch is properly aligned to the draw key passage in the axle end. **Reposition** the kingpin as needed.




Figure 27: Installing draw key

9. **Install** the draw key by gently tapping it through the axle end draw key bore until at least six threads are showing. If necessary, partially remove and reorient the kingpin for a better fit.

**NOTICE**

A misaligned kingpin or excessive force can cause damage to the draw key and/or kingpin during insertion.

10. **Install** the draw key nut (Figure 27) and **tighten** to the specified torque<sup>1</sup>.

**IMPORTANT:** For proper installation, the draw key threads should be at least 1/2-inch past the nut. If not, remove the draw key and repeat Step 10 and Step 11.

11. Perform steering knuckle vertical end play check.



Figure 28: Checking steering knuckle vertical end play

- A. **Turn** the knuckle to the straight-ahead position.
- B. **Affix** a magnetic base dial indicator on the axle and **place** the tip of the dial indicator vertically on top of the steering knuckle (not on the grease cap) as shown in Figure 28.

<sup>1</sup> Refer to FASTENER TORQUE SPECIFICATIONS on page 20 for wrench sizes and a complete list of torque specifications.



- C. Set the dial indicator to "0" zero.
- D. Use one of the following methods to **measure** the vertical clearance:
  - i. **Place** a pry bar between the knuckle and top of the axle center. **Pry** the knuckle up and measure the vertical end play.
  - ii. **Place** a block of wood and a hydraulic jack under the bottom of the knuckle. **Raise** the knuckle until the pointer on the dial indicator stops.

**NOTICE** It may be necessary to drill a hole in the block of wood to avoid the grease fitting.

- E. **Record** the dial indicator reading, vertical end play must be between 0.008" and 0.030".
  - iii. If the reading is greater than 0.030" add shims (Figure 29) between the top of the axle and the bottom of the upper kingpin connection.




Figure 29: Installing shims

### INSTALLING KINGPIN CAPS

The original kingpin caps and snap rings were likely damaged during removal and must be replaced with new caps available in kingpin service kits.




Figure 30: Installing kingpin cap assemblies

1. **Ensure** all surfaces and grooves in the steer kingpin housing assemblies, top and bottom, are clear of debris and contaminants.
2. **Install** upper and lower kingpin cap assemblies (Figure 30) ensuring the O-rings are not damaged during assembly.




Figure 31: Installing kingpin retaining rings

3. **Install** new retaining rings (Figure 31) snugly into inner groove of each kingpin housing assembly.
4. **Install** wheel-cut stop bolt and jam nut removed in [step 7 on page 14](#).
5. If necessary, **adjust** wheel-cut stop bolt to the length previously recorded in [step 6 on page 14](#),

**NOTE:** During reassembly, the bolt(s) must be installed to be the same length or readjusted. Refer to WHEEL-CUT ADJUSTMENT.

6. **Tighten** the jam nut to the specified torque<sup>1</sup>.

<sup>1</sup> A complete list of torque values can be found at [FASTENER TORQUE SPECIFICATIONS](#) on page 20.



7. Refer to SUSPENSION LUBRICATION on page 6 to inject grease into all steer kingpin housing assemblies.
8. **Verify** knuckle end play; refer to KINGPIN BUSHING INSPECTION on page 12.
  - A. If within tolerance, continue to the next step.
  - B. If not within tolerance, **determine cause** and make necessary repairs.
9. **Install** brake components, hub, drum and wheels. Refer to applicable wheel-end maintenance manual and L974 Drum Brake Maintenance Procedures for proper installation procedures.
10. **Install** tie rod and tie rod bracket refer to REATTACH TIE ROD AND REINSTALL TIE ROD BRACKET ON PAGES 10-11. **Restore** trailer to normal operating state.

## WHEEL-CUT ADJUSTMENT




Figure 32: Adjustable wheel-cut stop bolts

The maximum wheel-cut is set by adjusting the two wheel-cut stop bolts (Figure 32) on each end of the axle, rear side. These stop bolts are aligned to the knuckle for the purpose of limiting steer axle wheel-cut movement and prevent the wheels from contacting the trailer.

Wheel-cut was originally factory set according to trailer OEM specifications. Allowed tire clearance is listed in installation drawing<sup>1</sup> D-36237.

**IMPORTANT:** This is required for self-steer axles. Local regulations may exist which determine the wheel-cut angle.

1. **Loosen** stop bolt jam nut (Figure 32).

<sup>1</sup> An installation drawing is provided with each CONNEX® ST suspension. Generic versions are listed in Hendrickson literature number T61001 and available online at [www.hendrickson-intl.com/TrailerLit](http://www.hendrickson-intl.com/TrailerLit). Where duplication exists, refer to installation drawing.

WHEEL-CUT (DEG)	STOP BOLT LENGTH (IN)
30.00	1.439
28.00	1.599
25.00	1.849
20.00	2.239

<sup>3</sup> All values are nominal.

Table 6: Wheel-cut Stop Bolt Setting

2. **Adjust** each wheel-cut stop bolt length for the desired wheel-cut. If needed, refer to Table 6.
3. **Tighten** the locking jam nut to the specified torque<sup>2</sup>.

## BRAKE COMPONENTS

Brake components for self-steer axles are supported by the spider which is integrated into the knuckle design. For maintenance of CONNEX® ST drum brake components, refer to Hendrickson literature number L974 Drum Brake Maintenance Procedures.

## CAM TUBE




Figure 33: CONNEX® ST cam tube

The cam tube for CONNEX ST suspension systems is part of the knuckle weldment and cannot be replaced separately. Service includes inspection, lubrication (page 5) and, if needed, replacing bushings and seals. A service kit is available for replacing cam tube bushings and seals according to the procedure listed in Hendrickson literature number L974 Drum Brake Maintenance Procedures.

### NOTICE

Replacing lubricant purges any collected moisture, contaminants and degraded lubricant. Continue to add grease until fresh grease is visible at the purge point.

<sup>2</sup> A complete list of torque values can be found at FASTENER TORQUE SPECIFICATIONS on page 20.




## APPENDIX A: TERMS AND DEFINITIONS

The following terms apply to Self-Steer Axles.

- Camber** The vertical inward or outward angle of the wheel as viewed from the front or rear of the vehicle.
- Caster** The angle of rotation of the kingpin (top tilting forward or rearward) parallel to the vertical center of the wheel and perpendicular to the road surface.
- This angle is not adjustable. It is established during factory assembly of the axle/beam weldment.
- Lock-straight** The position where wheels (spindles) are locked into a straight position with the centerline parallel with the axle. If down, wheels must be in this position while the trailer moves in reverse direction.
- Toe** The angle at which, relative to forward motion, the leading edge of the wheels point inward (Toe-in, Y-X = positive value) or outward (Toe-out, Y-X = negative value) from the center line of the vehicle. The correct toe is important to minimize scrubbing of the tires. For checking and adjusting, refer to Hendrickson literature number L579 Alignment Procedure.
- Wheel-cut** Expressed in degrees, wheel-cut is the maximum angle of the steer axle inner wheel when turning. See WHEEL-CUT ADJUSTMENT on page 18.

**APPENDIX B: FASTENER TORQUE SPECIFICATIONS**



Self-steer axle bottom view  
 Figure 34: Self-steer axle fastener locations

ID <sup>1</sup>	FASTENER LOCATION	FASTENER	WRENCH / SOCKET SIZE	TORQUE		IMAGE <sup>1</sup>
				ft. lbs.	Nm	
1	Kingpin draw key	$\frac{7}{16}$ -20 UNF	$\frac{11}{16}$ inch	30±3	40±3	Figure 17 on page 13
2	Tie rod end castle nut (torque to specified value, then tighten to nearest cotter pin hole)	$\frac{7}{8}$ -14 UNF Castel nut	$1\frac{1}{4}$ inch	165±5 <sup>2</sup>	225±5 <sup>2</sup>	Figure 16 on page 13
3	Steering arm spacer bolts	1.0-8 x 8.0 large hex head bolt 1.0 flat washer (nut & bolt sides) 1.0-8 prevailing torque nut	$1\frac{1}{2}$ inch	680±10	920±10	
4	Tie rod end locking clamps	$\frac{5}{8}$ -11 x 3.0 large hex head bolt $\frac{5}{8}$ -11 prevailing torque nut	$\frac{15}{16}$ inch	55±5 <sup>3</sup>	75±5 <sup>3</sup>	Figure 1 on page 5
5	Lock-straight arm assembly pivot bolts	1.0-8 x 5.0 large hex head bolt 1.0-8 prevailing torque nut	$1\frac{1}{2}$ inch	<sup>4</sup>	<sup>4</sup>	Figure 5 on page 8
6	Lock-straight actuator plate pivot bolts	$\frac{5}{8}$ -11 x 4.0 large hex head bolt $\frac{5}{8}$ -11 prevailing torque nut	$\frac{15}{16}$ inch	<sup>4</sup>	<sup>4</sup>	Figure 5 on page 8
7	Lock-straight stop bolt and jam nut	$\frac{5}{8}$ -11	$\frac{15}{16}$ inch	140±10 <sup>3</sup>	190±10 <sup>3</sup>	Figure 5 on page 8
8	Tie rod bracket locking clamp bolts	$\frac{5}{8}$ -11 x 4.0 large hex head bolt $\frac{5}{8}$ flat washer (nut & bolt sides) $\frac{5}{8}$ -11 prevailing torque nut	$\frac{15}{16}$ inch	95±5 <sup>3</sup>	130±5 <sup>3</sup>	Figure 5 on page 8
9	Wheel-cut stop bolt and jam nut	$\frac{3}{4}$ -10 nut	$1\frac{1}{8}$ inch	140±10	190±10	Figure 32 on page 18
10	Lock-straight actuator mounting screws	$\frac{3}{8}$ -16	$\frac{9}{16}$ inch	30±5	40±5	Figure 6 on page 8
11	Pin lock chamber nut			41±2	56±2	

<sup>1</sup> Called out in Figure 34 and figure called out in last column.  
<sup>2</sup> After torquing, advance to nearest cotter pin hole.  
<sup>3</sup> Tighten only after adjustments have been made.  
<sup>4</sup> Tighten only until nut seats up against bracket. Feature must rotate freely.

Table 7: Self-steer axle fastener torque specifications







*Actual product performance may vary depending upon vehicle configuration, operation, service and other factors.*

**Call Hendrickson at 866.RIDEAIR (743.3247) for additional information.**



[www.hendrickson-intl.com](http://www.hendrickson-intl.com)

**TRAILER COMMERCIAL VEHICLE SYSTEMS**

2070 Industrial Place SE  
Canton, OH 44707-2641 USA  
866.RIDEAIR (743.3247)  
Fax 800.696.4416

**Hendrickson Canada**

2825 Argenta Road, Unit #2-4  
Mississauga, ON Canada L5N 8G6  
800.668.5360  
905.789.1030 • Fax 905.812-9423

**Hendrickson Mexicana**

Circuito El Marqués Sur #29  
Parque Industrial El Marqués  
Pob. El Colorado, Municipio El Marqués,  
Querétaro, México C.P. 76246  
+52 (442) 296.3600 • Fax +52 (442) 296.3601

T62001 Rev C 07-22 CN 038912 01-18 ECN 30019

© 2018 - 2022 Hendrickson USA, L.L.C. All Rights Reserved. All trademarks shown are owned by Hendrickson USA, L.L.C., or one of its affiliates, in one or more countries.  
Information contained in this literature was accurate at the time of publication. Product changes may have been made after the copyright date that are not reflected.

Printed in United States of America