


HUS® WHEEL-END INSPECTION PROCEDURE

Inspect HUS® wheel ends as follows to maintain proper operating condition and factory warranty:

HENDRICKSON

www.hendrickson-intl.com
866-RIDEAIR (743-3247)

L1076 Rev A 05-08 ECN 16815



Bearing status LED

INSPECT EVERY 2-4 WEEKS

- Check bearing condition by holding a magnet to the WEM. A blinking LED indicates bearing condition:

GREEN — Bearings operating properly

RED — Damage detected*

RED and GREEN — WEM malfunction*

*Contact Hendrickson at 866-743-3247 in the US or 800-668-5360 in Canada for further details.